

9. 12 V electrical panel terminal diagram

<i>Label</i>	<i>Description</i>
A	A Connector
1	Pressurized water system
2-5	Battery positive
3	Fridge thermostat relay
4	Bilge pump
6	Navigation equipment *
7	Shower drain pump
8	Battery negative
9	Autopilot
B	B connector
1	Navigation lights and compass
2-5	Battery positive
3	Saloon and chart table lights
4	Mooring light
6	Cabin and toilet lights
7	Steaming light*
8	Battery negative
9	HIFI * / 12 V outlet
C	C Connector
6	Engine battery test – T1
1/2/3/4	Fore watertank sensor – D1
9/10/11/12	Aft watertank sensor – D2
5	Fuel gauge sensor - G1
7	Water & fuel at level 0
8	Fuel gauge sensor - G2**
D	D Connector
1	Deck lights ** / Spares 1
2-5	Battery positive
4	Spares 2
7	Windlass control
8	Battery negative
	<i>Electrical wiring colours</i>
<i>n</i>	black
<i>r</i>	red
<i>w</i>	white
<i>o</i>	orange
<i>m</i>	brown
<i>b</i>	blue
*	Option
**	Not supplied

